

# Update of CFturbo<sup>®</sup> software


## PLEASE NOTE:


- Y Administrator rights are required for installation and licensing.
- Y CFturbo runs only on Windows XP/Vista/7.
- Y CFturbo has to be installed on all client-computers where it should be used.
- Y The CFturbo license file has to be placed on a windows share where all users have read/write access.
- Y License request and license activation have to be made on the same computer.

## ⌘ Check License Information

---

Before starting the update, the running license has to be checked.





For network license only:  
Keep in mind the path information for later usage in the update process.

# • Installation

## a) Installation from CD

Insert the CD in your CD drive.

The setup launcher should start automatically – otherwise start **AutoRun.exe** manually (see right).




Select **CFturbo 8.1**.





## b) Installation from download



Start the installation program **cfturbo8\*setup.exe**.





You can select "Yes" to install CFturbo 8.1 to the existing location and overwrite the old version.





# Ž Licensing

## (I) nodelocked license


The nodelocked (local) license remains valid. No activities are needed.

## (II) Network license


You have to reselect the existing license.



### a) SELECT existing license

After starting CFturbo® you will get the following message indicating that there is no valid license available. Please click "OK".




The "Licensing Wizard" dialog starts automatically (or open menu Edit | Licensing).





Navigate to the path where your network license file is located. **Remember:** You took a note of this path before starting the update.



## b) SHOW current license information

You can recheck you license information after selecting the network license.

